



Thank you for purchasing the **SAFESippy Cup** from **PlasticFreeBottles.com**

Before using your SAFESippy carefully read the instructions on the back of the package.

Make sure to wash all parts in warm soapy water before using the cup. The SAFESippy is top rack dishwasher safe.

Although you normally do not need to remove the thermoplastic sleeve that protects the cup, in the event that the sleeve is removed you can reinstall it by following these simple steps.

- Turn the sleeve inside out.
- Align the inside bottom of the protective sleeve with the bottom of the stainless steel cup.
- Carefully roll the sleeve over the stainless steel cup.

If you have any questions concerning your SAFESippy cup feel free to contact us at info@plasticfreebottles.com or call us at (514) 693-9636.